

RUBBER BALL BEARING BOOTS

Rubber boots can be used in Snap Together Pillow Block Sets and with our Zinc Plated Stamped Flanges. Made from status conductive nitrile rubber.

<i>Rubber Boot</i>	<i>Spherical OD of Ball Bearing</i>
R-4	40MM
R-5	47MM
R-6	52MM
R-7	62MM

The Rubber Boot or Grommet surrounds the ball bearing and fits in between the base and top strap of the Pillow Block Set.

A Pillow Block Set without turned down edges on the top strap, and turned up edges on the base will not work, as the rubber flows out of the unit in use when any thrust is applied.

The above SAS Bearings Pillow Block Sets have the proper edges on both base and top strap. This is the type of unit, where the base and top strap have the "Snap Together" feature.



RUBBER BALL BEARING BOOTS OR GROMMETS		
R-4	Bearing Series 201 and 202	For 40 M/M Bearing — Mount with 47 MM Housing
R-5	204	For 47 M/M Bearing — Mount with 52 MM Housing
R-6	205	For 52 M/M Bearing — Mount with 62 MM Housing
R-7	206	For 62 M/M Bearing — Mount with 72 MM Housing
We Carry These In Stock		